



MDT 6x4 Toyota Hilux

MAINTENANCE SCHEDULE



- IMPORTANT -

This manual gives an overview of the maintenance schedule for an MDT 6x4 Toyota Hilux. For complete detail on maintenance operations, please refer to the OEM owner's manual.

Please note that this manual applies to all models and may include explanations for equipment not installed on your vehicle.

The specifications and descriptions were accurate at the time of issue. Since improvement is a constant goal of Multidrive Technology, we reserve the right to make changes at any time without notice and without incurring any obligation.

MDT 6x4 Toyota Hilux Maintenance Schedule

SERVICE INTERVAL:

First of either Distance travelled or months past

Maintenance	T	Tighten and/or adjust as necessary
Operations:	I	Inspect and correct or replace as necessary
	R	Replace, change or lubricate
	L	Lubricate
	C	Cleaning



	MONTHS	3	6	12	18	24	30	36	42	48	54	60	66	72	78	84	90	96	102	108	114	120
	Km x 1,000	5	10	20	30	40	50	60	70	80	90	100	110	120	130	140	150	160	170	180	190	200
BASIC ENGINE COMPONENTS																						
1	V-ribbed drive belt (Diesel)												I		I		I		I		I	
2	Engine oil		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
3	Engine oil filter		R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R	R
4	Cooling and heater system (see note 1)					I				I		I		I		I		I		I		I
5	Engine coolant – include intercooler coolant (Toyota Genuine SLLC) (see note 2)					I				I								R				I
6	Exhaust pipes and mountings			I		I		I		I		I		I		I		I		I		I
ELECTRICAL SYSTEM																						
7	Battery		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
FUEL SYSTEM																						
8	Fuel filter (Diesel)					R				R					R			R				R
9	Water sediment accumulator (Diesel)		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
10	Engine air cleaner filter (Diesel) (see note 3)		I	I	R	I	I	R	I	I	R	I	I	R	I	I	R	I	I	R	I	I
11	Air flow meter (MAF sensor) (Diesel) (see note 4)		C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C	C
12	Diesel smoke (Diesel)					I				I				I				I				I
13	Fuel tank cap, fuel lines and connections (Diesel)					I				I				I				I				I
CHASSIS AND BODY																						
14	Brake pedal and parking brake			I		I		I		I		I		I		I		I		I		I
15	Brake linings and drums					I				I				I				I				I
16	Brake pads and discs		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
17	Brake fluid		I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R	I	I	I	R
18	Clutch fluid (M/T)		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
19	Brake pipes and hoses			I		I		I		I		I		I		I		I		I		I
20	Vacuum pump for brake booster (Diesel) (see note 5)																					
21	Power steering fluid		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
22	Steering wheel and linkage					I				I				I				I				I
23	Lubricate propeller shaft		L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L	L
24	Tighten propeller shaft bolts		T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T	T
25	Drive shaft boots		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
26	Suspension ball joints and dust covers			I		I		I		I		I		I		I		I		I		I
27	Manual transmission oil					I				I				I				I				I
28	Automatic transmission fluid					I				I				I				I				I
29	Automatic transmission fluid cooler hoses and connections					I				I				I				I				I
30	Transfer oil (4x4)					I				I				I				I				I
31	Front differential oil (4x4)			I		R		I		R		I		R		I		R		I		R
32	Rear differential oil			I		R		I		R		I		R		I		R		I		R
33	Front and rear suspensions (4x4)			I		I		I		I		I		I		I		I		I		I
34	Front and rear wheel bearing grease			R		R		R		R		R		R		R		R		R		R
35	Bolts and nuts on chassis and body (see note 6)											T										T
36	Accessory items (see note 7)		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
37	Tyres and inflation pressures		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
38	Rotate wheels		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
39	Balance front wheels		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
40	Driver's floor mat – fitment and retention		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
41	Lights, horns, wipers and washers		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
42	Seatbelt, webbing condition, buckle and retractor mechanism operation		I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I	I
43	Air conditioner filter				R			R		R				R			R			R		
44	Air conditioner, including refrigerant level			I		I		I		I		I		I		I		I		I		I

Notes:

- Check that the radiator and condenser are not blocked with leaves, dirt, or insects, and the hose connections for installation condition and corrosion.
- Replace the engine coolant initially at 96 months or 160,000 km (whichever occurs first), then every 48 months or 80,000 km (whichever occurs first). Use Genuine Toyota Super Long Life Coolant (SLLC) or a similar high quality ethylene glycol based non-silicate, non-amine, non-nitrate, and non-borate coolant with long-life hybrid organic acid technology.
- For Diesel engine vehicles frequently operating on unmade roads or extremely dusty conditions with dry air inspect every 5,000 km.
- MAF sensor removal is not required for perform cleaning. Do not use chemicals etc to clean MAF sensor. Refer to repair manual for correct cleaning method.
- Replace the blades with new ones. Never reuse the blades.
- For seat mounting bolts, front and rear suspension retaining bolts and leaf springs retaining U-bolts.
- Inspect for correct fitment. Check tension of retaining bolts for any heavy metal accessory (towbar, bulbar, side steps, etc.).

Reference: Hilux / Fortuner Owner Manual, Issue: 2203-04


MDT 6x4 Specific Maintenance Operations

This schedule only applies to the MDT components on the vehicle and should be read in conjunction with the Toyota Service and Operating Manual.


Grease Points

The following points should be lubricated at 10,000 km intervals or more frequently under severe conditions, per the Toyota Operators Handbook.

Suspension load share beam pivots (2 points)



Suspension spring pins/bushes (12 points)



We recommend a high-quality grease with a molybdenum-disulphide lithium base for chassis lubrication.